

HERE ARE THE EGRESS PROCEDURES FOR PATTY WAGSTAFF'S EXTRA 300S
TO OPEN THE CANOPY

Reach through the small window on the left side of the canopy and squeeze the two red handle together. The canopy hinges open to the right.



THE PILOT IS STRAPPED INTO THE COCKPIT WITH A 5 PLACE HARNESS
THERE ARE TWO QUICK RELEASES THAT MOVE IN OPPOSITE DIRECTIONS
PULL THE BOTTOM ONE LEFT AND THE TOP ONE RIGHT



THE PILOT WILL BE WEARING THE PARACHUTE AND THERE'S NO NEED TO TAKE IT OFF
BEFORE TAKING PILOT OUT OF COCKPIT IN AN EMERGENCY

THE PARACHUTE HAS THREE QUICK RELEASE BUCKLES - ONE IN FRONT AND ONE ON EACH
SIDE, A LITTLE BEHIND THE PILOT'S HIPS



IF YOU HAVE TO REMOVE PILOT FROM AIRPLANE, THEY MIGHT STILL HAVE THEIR HEADSET ON. IT IS SECURED AROUND THE NECK WITH A VELCRO STRAP